

## RICOH PRODUCT QUICK GUIDE

### OBTAIN A METER READING

1. Select Settings
2. Select Counter
3. The counter will appear. You can record the counter manually or you can choose to print it.

